

<p><b>IGI 4786</b></p>	
<p><b>Wax Type:</b></p>	<p>Pre-Blended Paraffin</p>
<p><b>Application:</b></p>	<p>Containers Only</p>
<p><b>Properties:</b></p>	<p>Melt Point: 124° F Flash Point: 380° F</p>
<p><b>Recommended Pouring Temperature:</b></p>	<p>160° - 170° F</p>
<p><b>Benefits:</b></p>	<ul style="list-style-type: none"> <li>• A smooth and creamy container blend</li> <li>• Does not require added additives</li> <li>• Just add color and scent</li> <li>• Holds above the average amount of fragrance oil,6-10%.</li> <li>• Provides good adhesion to glass containers.</li> <li>• Great scent throw</li> </ul>
<p><b>General Guidelines:</b></p> <p>Please remember, these are only general guidelines and individual results may vary.</p> <p>Experimentation and testing are always the best way to determine the best methods for your application.</p>	<ul style="list-style-type: none"> <li>• Preheat glass containers for better adhesion</li> <li>• Heat wax to approx. 160°-170°F</li> <li>• Add fragrance and dye, stir thoroughly, then pour into containers.</li> <li>• Allow candle to cool as slowly as possible. DO NOT place in a water bath or refrigerator to accelerate the cooling process.</li> <li>• Candles will shrink ("well") on top</li> <li>• When candles are almost completely cooled and solidified, then do the re-pour/top off with the leftover wax. Be careful to re-pour only up to the original fill line</li> </ul>